



ATTENTION!

CAUTION:

Before drilling for drain tubes, verify area is free and clear of obstructions below the truck bed.

Optional Drilling Locations:



Inspect area below bed floor to insure proper clearance before drilling



Corner of wheel well



Existing hole - careful not to drill too far.



